



Congratulations on your purchase of a Caso Design® Dry Age Fridge, imported by Pro-Line Australia.

Please read through this notice and the instruction manual carefully before using or installing the product and ensure that both are kept in a safe place for future reference.

The system must be properly installed and located in accordance with the instructions before it is used.

During the setup of this product if you have any questions/ comments/ issues DO NOT RETURN TO STORE. FOR SERVICE AND TECHNICAL ADVICE VISIT www.prolineaustralia.com.au/contact

Pro-Line Australia is the importer of CASO design® Dry Age Fridges, the details found in this notice are in addition to the international user manual provided and cover warranty and other details particular to products purchased in Australia or New Zealand.

For specifications on your product please refer to the rating label applied to the appliance.

User Responsibilities-

- To ensure that food products are conserved at suitable temperatures and not exceeding the permitted period.
- To be aware of the regulations governing the conservation of food and to observe any hygiene requirements that may be applicable.

WARNING: The appliance must be stabilised in an upright position for at least 24 hours before being plugged in and switched on.

R600A REFRIGERANT WARNING: This appliance contains R600a refrigerant. Avoid safety hazards by carefully installing, handling, servicing and disposing of this appliance.

WARNING: This appliance contains insulation formed with flammable blowing gases. Avoid safety hazards by carefully disposing of this appliance.

WARNING: Keep ventilation openings in the appliance's cabinet clear of obstruction.

WARNING: This appliance is suitable for indoor use only and is intended to be used exclusively as stated in the user manual. This appliance is intended to be used in household and similar applications.

Due to manufacturing alterations the product may vary slightly from that pictured and presented in the user manual. It may or may not be Wi-fi enabled.

At the end of the appliances service life, it must be disposed of correctly, please contact your local council or authority to determine the best disposal method.

Pro-Line Australia warrants this product as specified on the following page and replaces the guarantee provided in the user manual, in the first instance of a problem please contact us via the below information:

Pro-Line Australia PO Box 4187 Norwood South LPO South Australia 5067 Email: info@prolineaustralia.com.au
Web:www.prolineaustralia.com.au

¶/prolineaustralia

Ø/proline_australia

Your Pro-Line Australia 24-month Repair or Replacement Warranty

Pro-Line warrants this appliance to the first purchaser and subject to the stated conditions:

This warranty only applies to appliances purchased and used in Australia or New Zealand and covers any defects in material or workmanship in the manufactured product within the first 24 months of warranty, from the date of purchase.

To make a warranty claim you must visit Pro-line online at www.prolineaustralia.com.au/warrantyclaim

If a product is found to be faulty there is a 90 day return policy from the date of purchase. Products returned to store MUST be accompanied by a valid proof of purchase.

For warranty claims outside of 90 days from date of purchase, product will be repaired or replaced at our discretion. Repair or replacement costs of the product will be covered under warranty by Pro-line.

Goods presented for repair may be replaced by refurbished goods of the same type rather than being repaired. Refurbished parts may be used to repair the goods. The benefits given to you by this warranty are in addition to other rights and remedies of the consumer law in relation to the goods or services to which this warranty relates.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if goods fail to be of acceptable quality and the failure does not amount to a major failure.

Conditions of this Warranty:

- 1. This product has been fully installed in accordance with the user manual installation instructions.
- 2. The warranty extends only to repairing or replacing any component that proves to be defective in material or workmanship.
- 3. The warranty does not cover defects occasioned by misuse, alterations, accidents, or used for other than the intended purpose.
- 4. The warranty does not cover damage to the product caused by accident, fire, floods, power surges or black outs.
- 5. Proof of purchase is required for warranty claims. Please keep purchase receipt in a safe place.



Pro-Line Australia PO Box 4187 Norwood South LPO South Australia 5067

Email: <u>info@prolineaustralia.com.au</u>
Web:www.prolineaustralia.com.au